













## **OPEN THE HOOD!**

Keep Hood Open & ensure Grill Control Knobs are in the OFF position

### **1. OPEN THE DRAWER**

- Stack charcoal briquettes or wood into a pyramid-shaped pile on top of the charcoal grate or pan.
- We recommend using 1 Kg (approximately 30 briquettes) to start your fire, adding more as needed. – CLOSE DRAWER -

### **2. LIGHT THE MAIN BURNERS**

- Turning the Right KNOB counter-clockwise to HIGH
- You will hear a loud click as the electronic lighter produces a spark. Listen for the sound of the gas igniting and look for a flame through the cooking grids. If the burner does not light on the first try, repeat immediately.
- If the burner does not light in 5 seconds then wait five minutes until the gas clears before attempting to light it again. Repeat the procedure or try the manual lighting options in manual.

### **3. SUCCESSFUL LIGHTING**

- Upon lighting the grill repeat the process on the other IR Burner you wish to light - see below:

### **4. LIGHT THE BACK IR-BURNER**

- SLOWLY turn the Left KNOB counter-clockwise to HIGH
- You will hear a loud click as the electronic lighter produces a spark. Listen for the sound of the gas igniting and look for a flame spreading across the ceramic plates from left to right. If the burner does not light on the first try, repeat immediately.
- If the burner does not light in 5 seconds then wait five minutes until the gas clears before attempting to light it again. Repeat the procedure if not lighting. The back IR-Burner requires additional time for first time lighting.

### **5. SHUT OFF BURNERS**

- To shut off the burners, rotate the knob and turn to OFF.
- It is normal to hear a popping sound when the burners are turned off.